

HOW TO CREATE SEAMLESS PANEL CROSSOVERS

4.8437 in

7.8438 in

MEASURE PANELS (ABOVE) THEN
BUILD BOX (BELOW) TO BE USED AS REFERENCE

7.8438 in x 4.8437 in

CAD 016361

HOW TO CREATE SEAMLESS PANEL CROSSOVERS

USE THE REFERENCE BOX AS CLIPPING MASK TO ART



CAD.016361

HOW TO CREATE SEAMLESS PANEL CROSSOVERS

CAD 016361

ANCHOR TOP LEFT BOX TO TOP LEFT CORNER OF DIE



HOW TO CREATE SEAMLESS PANEL CROSSOVERS

COPY THEN ROTATE 180°
ANCHOR TOP RIGHT BOX TO TOP RIGHT CORNER OF DIE

ANCHOR TOP LEFT BOX TO TOP LEFT CORNER OF DIE

CAD 016361

